

Spinnenfänger



Anleitung
Instructions

Wie bedienen Sie den „Spinnenfänger“?

- Am Griff des Spinnenfängers betätigen Sie den Auslöser, um die Fangborsten zu öffnen.
- Mit gedrücktem Auslöser und somit geöffneten Fangborsten nähern Sie sich dem Insekt, hierbei sollten die gespreizten Borsten das Tier komplett umschließen.
- Haben Sie den Spinnenfänger über dem Insekt platziert, lassen Sie den Auslöser los, damit die Borsten das Insekt fassen und greifen können.
- Prüfen Sie im Anschluss, ob der Spinnenfänger das Tier auch allumfänglich aufgenommen hat.
- Nun können Sie das Insekt mithilfe des Spinnenfängers nach draußen tragen und dieses durch nochmaliges Drücken des Auslösers freilassen.

How do you operate the “Spider Catcher”?

- Press and hold down the trigger on the handle of the spider catcher to keep the insect-trapping bristles open.
- Approach the insect and make sure the wide-open bristles completely enclose it.
- Then, release the trigger so that the bristles grasp and trap the insect.
- Finally, check whether the insect is trapped in the spider catcher.
- Now, use it to carry the insect and release it in the open by pressing the trigger again.